

Case de marcat fiscale - procente TVA

Varianta 1 - 19% adaugat pe pozitia 4

Activa			Datecs			Eltrade			Euro			Optima			SuccesM		
TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft
20%	A	1	20%	A	1	20%	A	0	20%	A	1	20%	A	1	20%	A	1
9%	B	2	9%	B	2	9%	B	1	9%	B	2	9%	B	2	9%	B	2
5%	C	3	5%	C	3	5%	C	2	5%	C	3	5%	C	3	5%	C	3
19%	D	4	19%	D	4	19%	D	3	19%	D	4	19%	D	4	19%	D	4
0%	E	5	0%	E	7	0%	E	4	0%	E	5	0%	E	5	0%	E	5

Varianta 2 - 19% inlocuieste 20%

Activa			Datecs			Eltrade			Euro			Optima			SuccesM		
TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft
19%	A	1	19%	A	1	19%	A	0	19%	A	1	19%	A	1	19%	A	1
9%	B	2	9%	B	2	9%	B	1	9%	B	2	9%	B	2	9%	B	2
5%	C	3	5%	C	3	5%	C	2	5%	C	3	5%	C	3	5%	C	3
0%	D	4	0%	D	4	0%	D	3	0%	D	4	0%	D	4	0%	D	4
0%	E	5	0%	E	7	0%	E	4	0%	E	5	0%	E	5	0%	E	5

Marcaj bleu = setari necesare in casa de marcat

Marcaj galben = locatii declarate inactice

Scris cu rosu = setari necesare in casa de marcat doar daca efectuati vanzari cu TVA ZERO

Setarile implicite pana la versiunea 3.5.7 - 19.12.2016

Activa			Datecs			Eltrade			Euro			Optima			SuccesM		
TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft	TVA	Casa	Soft
20%	A	1	20%	A	1	20%	A	0	20%	A	1	20%	A	1	20%	A	1
9%	B	2	9%	B	2	9%	B	1	9%	B	2	9%	B	2	9%	B	2
5%	C	3	5%	C	3	5%	C	2	5%	C	3	5%	C	3	5%	C	3
0%	?	0	0%	D	4	0%	D	3	0%	E	5	0%	E	5	0%	E	5